



BOSA 400 Quick Start Guide

Included material:

- BOSA mainframe
- Power cord
- USB stick with User and Programming Guides

Required connections

- Rear panel connections
 - Power cord for the BOSA.

Starting the system

- Turn on BOSA400 by pressing the power button on the left of the front panel. After a few moments a Windows login screen will appear. Use the account "User" with password "1234". Password can be changed from the main application.
 - We recommend to change this Password if the Unit is intended to be used in an Ethernet network for security reasons.
- After login and program loading, a mode selector Window will appear.
 - Press the BOSA button to enter the main screen for the active devices spectrum measurement.
 - Press the Component Analyzer to enter the main screen for the Passive Devices characterization spectrum measurement.
- Press the green button on the top right of the screen. It will turn grey during startup and red when startup has finished.
- For information on the usage of BOSA interface please refer to the User Manual inside the USB stick card.